

Signal Encoding Techniques

ITS323: Introduction to Data Communications
CSS331: Fundamentals of Data Communications

Sirindhorn International Institute of Technology
Thammasat University

Prepared by Steven Gordon on 3 August 2015
ITS323Y15S1L04, Steve/Courses/2015/s1/its323/lectures/signal-encoding-techniques.tex, r3920

Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals

Introduction

Digital Data, Digital Signals

Digital Data, Analog Signals

Analog Data, Digital Signals

Analog Data, Analog Signals

Signal Encoding Techniques

- ▶ Signals transmitted chosen to optimize use of transmission medium
 - ▶ E.g. conserve bandwidth, minimize errors
- ▶ **Digital signaling**: digital or analog data **encoded** into digital signal
- ▶ **Analog signaling**: digital or analog data transmitted by analog **carrier signal** using **modulation**
 - ▶ Baseband signal is the input data signal
 - ▶ Carrier signal has frequency $f_{carrier}$
 - ▶ Modulated signal is output

Encoding and Modulation Techniques

Signal Encoding


Introduction

Digital Data,
Digital Signals


Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



(a) Encoding onto a digital signal



(b) Modulation onto an analog signal

Reasons for Using Different Techniques

Digital data, digital signal: Equipment less complex/expensive than digital-to-analog modulation equipment

Analog data, digital signal: Permits use of digital transmission equipment

Digital data, analog signal: Some media only propagate analog signals, e.g. optical fibre, wireless

Analog data, analog signal: Some analog data can easily be transmitted as baseband signals, e.g. voice; enables multiple signals at different positions in spectrum to share transmission media

Contents

Signal Encoding

Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals

Introduction

Digital Data, Digital Signals

Digital Data, Analog Signals

Analog Data, Digital Signals

Analog Data, Analog Signals

Digital Data, Digital Signals

- ▶ Digital signal: sequence of discrete voltage pulses
- ▶ Each pulse is a **signal element**
- ▶ Binary data transmitted by encoding each bit (data element) into signal elements
 - ▶ E.g. binary 1 represented by lower voltage level, binary 0 for higher level
- ▶ Data rate = data elements or bits per second
- ▶ Signaling or modulation rate = signal elements per second (baud)

Receiver Interpreting Incoming Signal

Signal Encoding


Introduction

Digital Data, Digital Signals

Digital Data, Analog Signals

Analog Data, Digital Signals

Analog Data, Analog Signals



- ▶ Important factors for successful reception: SNR, data rate, bandwidth
 - ▶ Increase in data rate increases bit error rate (BER)
 - ▶ Increase in SNR decreases BER
 - ▶ Increase in bandwidth allows increase in data rate
- ▶ Also **encoding scheme** . . .

Nonreturn to Zero-Level (NRZ-L)

- 0 = high level
- 1 = low level

Nonreturn to Zero Inverted (NRZI)

- 0 = no transition at beginning of interval (one bit time)
- 1 = transition at beginning of interval

Bipolar-AMI

- 0 = no line signal
- 1 = positive or negative level, alternating for successive ones

Pseudoternary

- 0 = positive or negative level, alternating for successive zeros
- 1 = no line signal

Manchester

- 0 = transition from high to low in middle of interval
- 1 = transition from low to high in middle of interval

Differential Manchester

- Always a transition in middle of interval
- 0 = transition at beginning of interval
- 1 = no transition at beginning of interval

B8ZS

- Same as bipolar AMI, except that any string of eight zeros is replaced by a string with two code violations

HDB3

- Same as bipolar AMI, except that any string of four zeros is replaced by a string with one code violation

Digital Signal Encoding Formats

Signal Encoding


Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



Comparing Different Encoding Schemes

Signal Spectrum

- ▶ Desire no high frequency components so less bandwidth is required
- ▶ Desire no dc component so ac coupling can be used (reduces bit error rate)
- ▶ Concentrate transmitted power in middle of bandwidth

Clocking and Synchronization

- ▶ Transmitted signal can be used by receiver to synchronise bit timing

Comparing Different Encoding Schemes

Error Detection

- ▶ Receiver can detect some bit errors from the received signal

Signal Interference


- ▶ Provide good performance (few bit errors) in presence of noise

Cost and Complexity

- ▶ Desire smaller signaling rate to achieve a given data rate

Spectral Density of Various Signal Encoding Schemes

Narrower is better



Improving on NRZ

Multilevel Binary Schemes

- ▶ Bipolar AMI, Pseudoternary
- ▶ Use more than two signal levels
- ▶ No dc component, simple error detection, no loss of synchronization (in some cases), small bandwidth needed
- ▶ Requires more transmit power for same level of BER as two-level schemes

Biphase Schemes

- ▶ Manchester, differential Manchester
- ▶ More than 1 transition per bit
- ▶ Similar features to multilevel schemes, but larger bandwidth required

Improving Synchronization

- ▶ In Bipolar AMI a long sequence of 0's makes it difficult for the receiver to synchronize
- ▶ Solution: if long sequence of same bit, replace with special sequence of bits
- ▶ B8ZS (Bipolar with 8-zeros substitution)
 - ▶ If 8 0's and last pulse was positive, replace 8 0's with $000 + -0 - +$
 - ▶ If 8 0's and last pulse was negative, replace 8 0's with $000 - +0 + -$
- ▶ HDB3 (High density bipolar 3-zeros)

Polarity of Preceding Pulse	Number of Bipolar Pulses (ones) since Last Substitution	
	Odd	Even
-	000-	+00+
+	000+	-00-

Encoding Rules for B8ZS and HDB3

Signal Encoding


Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



B = Valid bipolar signal

V = Bipolar violation

Example Technologies using Encoding Schemes

- ▶ NRZ/NRZI: RS-232, HDLC, USB, ...
- ▶ Manchester: Ethernet, Token Ring, ...
- ▶ Multilevel Binary: US T-carrier and European E-carrier telecommunication systems

Contents

Signal Encoding

Introduction

Digital Data,
Digital Signals

**Digital Data,
Analog Signals**

Analog Data,
Digital Signals

Analog Data,
Analog Signals

Introduction

Digital Data, Digital Signals

Digital Data, Analog Signals

Analog Data, Digital Signals

Analog Data, Analog Signals

Digital Data, Analog Signals

- ▶ Transmit digital data over media that only support analog signals, e.g. telephone network, microwave systems
 - ▶ Telephone network designed to transmit signals in voice-frequency (300 to 3400 Hz)
 - ▶ **Modems** (modulator-demodulator) convert digital data to signals in this frequency range
- ▶ 3 basic modulation techniques:
 1. Amplitude Shift Keying (ASK)
 2. Phase Shift Keying (PSK)
 3. Frequency Shift Keying (FSK)
- ▶ Resulting signal occupies bandwidth centred on carrier frequency

Modulation of Analog Signals for Digital Data

Signal Encoding


Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



Comparing the Shift Keying Schemes

Amplitude Shift Keying

- ▶ Inefficient modulation technique
- ▶ Used on voice lines < 1200 bps and optical fibre

Frequency Shift Keying

- ▶ Used on voice lines, coaxial cable, HF radio systems
- ▶ Extended with M frequencies: improve efficiency, higher error rate

Phase Shift Keying

- ▶ Used in wireless transmission systems
- ▶ Extended with M phases, e.g. QPSK ($M = 4$),
- ▶ Combined with ASK: Quadrature Amplitude Modulation (QAM); used in ADSL and wireless systems

Example Technologies using Shift Keying

- ▶ ASK: Optical fibre, RFID
- ▶ FSK: HF/shortwave radio, UHF/VHF radio comms, RFID
- ▶ PSK and QAM: mobile phones, Wi-Fi, cable modems, xDSL, DVB, ...

Contents

Signal Encoding

Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

**Analog Data,
Digital Signals**

Analog Data,
Analog Signals

Introduction

Digital Data, Digital Signals

Digital Data, Analog Signals


Analog Data, Digital Signals

Analog Data, Analog Signals

Analog Data, Digital Signals

- ▶ Two options:
 1. Convert analog data to digital data; transmit digital data as digital signal (e.g. using NRZ)
 2. Convert analog data to digital data; modulate the data to transmit as analog signal (e.g. PSK)
- ▶ How to digitize analog data?
 - ▶ **Codec** converts analog to digital data, and recovers analog data from digital data
 - ▶ Consider two techniques used in codecs: Pulse Code Modulation and Delta Modulation

Pulse Code Modulation



1. Divide the normalised input magnitude into 2^n different levels, with corresponding code numbers
2. Sample analog input every T_s seconds \rightarrow pulse amplitude modulation (PAM) value
3. Map PAM value to nearest code number
4. Convert code number to n -bit binary PCM code

See also "Pulse Code Modulation" handout

Pulse Code Modulation Example

Signal Encoding


Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



Sampling Theorem

If a signal $f(t)$ is sampled at regular intervals of time and at a rate higher than twice the highest signal frequency, then the samples contain all the information of the original signal

- ▶ Example: voice is between 0 and 4000 Hz; sampling at 8000 samples per second is sufficient to reproduce analog voice at receiver
- ▶ BUT ... quantizing the PAM values introduces error (or noise); each additional bit increases SNR by 6 dB
- ▶ Good voice reproduction can be achieved with 128 quantization levels (7-bit coding)

Improving PCM with Nonlinear Coding

Signal Encoding

Introduction


Digital Data, Digital Signals

Digital Data, Analog Signals

Analog Data, Digital Signals

Analog Data, Analog Signals

- ▶ Linear spacing of quantization levels can result in poor reproduction of weak signals
- ▶ Non-linear encoding: more steps for low amplitude, less steps at high amplitude
- ▶ Can lead to significant improvement for voice



Delta Modulation

- ▶ Popular alternative to PCM
- ▶ Input analog data approximated by staircase function
- ▶ Moves up/down by one quantization level (δ) each sampling interval (T_s)
- ▶ If signal goes up, bit 1 is output; otherwise bit 0

Example of Delta Modulation

Signal Encoding


Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



Contents

Signal Encoding

Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

**Analog Data,
Analog Signals**

Introduction

Digital Data, Digital Signals

Digital Data, Analog Signals

Analog Data, Digital Signals

Analog Data, Analog Signals

Modulating Signals

- ▶ Combine input signal, $m(t)$, and carrier at frequency f_c to produce signal $s(t)$ whose bandwidth is centered on f_c
- ▶ Why? If analog transmission systems . . .
 - ▶ Digital data must be converted to analog form (e.g. PSK, FSK)
 - ▶ Analog signals may need to be transmitted at higher frequency than analog data
 - ▶ Changing frequency of analog data allows for frequency division multiplexing (sending different analog data in one analog signal)
- ▶ Principal techniques: amplitude modulation (AM), frequency modulation (FM), phase modulation (PM)

Amplitude Modulation of a Sine-Wave Carrier by a Sine-Wave Signal


Introduction

Digital Data,
Digital Signals


Digital Data,
Analog Signals

Analog Data,
Digital Signals


Analog Data,
Analog Signals



Carrier



Modulating sine-wave signal



Amplitude-modulated (DSB-TC) wave

Phase Modulation of a Sine-Wave Carrier by a Sine-Wave Signal




Introduction

Digital Data,
Digital Signals

Digital Data,
Analog Signals

Analog Data,
Digital Signals

Analog Data,
Analog Signals



Frequency Modulation of a Sine-Wave Carrier by a Sine-Wave Signal


Introduction

Digital Data,
Digital Signals


Digital Data,
Analog Signals

Analog Data,
Digital Signals


Analog Data,
Analog Signals



Carrier



Modulating sine-wave signal



Frequency-modulated wave